


15-441
15-641 **Computer Networking**

Virtual Circuits, MPLS, VLANs
Peter Steenkiste

Fall 2015


www.cs.cmu.edu/~prs/15-441-F15

Outline




- Circuit switching refresher
- Virtual Circuits - general
 - Why virtual circuits?
 - How virtual circuits? -- tag switching!
- Two modern implementations
 - ATM - teleco-style virtual circuits
 - MPLS - IP-style virtual circuits
- Virtual LANs
 - How do they differ?



Circuit Switching



- Source first establishes a connection (circuit) to the destination.
 - Each router or switch along the way may reserve some bandwidth for the data flow
- Source sends the data over the circuit.
 - No destination address needed - routers know the path
- The connection is torn down.
- Example: traditional telephone network.




Circuit Switching



- Switch remembers how to forward data
 - No addresses!
- Many options
 - Between specific wires (circuit = wire)
 - Between timeslots (TDMA on each wire)
 - Between frequencies (FDMA on each wire)

Circuit Versus Packet Switching



Circuit Switching


- Fast switches can be built relatively inexpensively
- Inefficient for bursty data
- Predictable performance (e.g. hard QoS)
- Requires circuit establishment before communication

Packet Switching


- Switch design is more complex and expensive
- Allows statistical multiplexing
- Difficult to provide QoS guarantees
- Data can be sent without signaling delay and overhead

Can we get the benefits of both?


Virtual Circuits



- Each wire carries many “virtual” circuits.
- Forwarding based on virtual circuit (VC) identifier
 - IP header: src, dst, etc.
 - Virtual circuit header: just “VC”
 - A path through the network is set up when the VC is established
 - Can eue statistical multiplexing for efficiency
- Can support wide range of quality of service.
 - No guarantees: best effort service
 - Weak guarantees: delay < 300 msec, ...
 - Strong guarantees: e.g. equivalent of physical circuit





Virtual Circuits Versus Packet Switching



- Many similarities:
 - Forwarding based on “address” (VCID or dest address)
 - Statistical multiplexing for efficiency
 - Must have buffers space on switches
- Virtual circuit switching:
 - Uses short connection identifiers to forward packets
 - Switches know about the connections so they can more easily implement features such as quality of service
 - Switches are stateful: VC connection state cannot be lost
- Packet switching:
 - Use full destination addresses for forwarding packets
 - Can send data right away: no need to establish a connection first
 - Switches are stateless: easier to recover from failures
 - Adding QoS is hard


Virtual Circuit Forwarding



Address	Next Hop
VC1	3
VC2	3
VC3	4
VC4	?
VC5	?

- Address used for look up is a virtual circuit identifier (VC id)
- Forwarding table entries are filled in during signaling
- VC id is often shorter than destination address

VC versus Packets: Control over Path




Payload

VCI

Payload

Dst



R1 packet forwarding table:

Dst R2

R1 VC table:



VC 1 R2

VC 2 R3

Different paths to same destination!



(useful for traffic engineering!)

How to Pick a VC Id?



- When B establishes green virtual circuit, how does it know what VC ids are available?
- Even worse: every VC id may already be used on a link along the path to the destination
- Solution: VC id swapping

VC id Swapping




Address	Next Hop	Next id
VC1 = 1	3	2
VC2 = 2	3	3
VC3 = 1	4	1
VC4 = 2	3	1

- Look up is based on VC id in header + incoming port number
- Forwarding table specifies outgoing port and new VC id
- VC id conflicts can be resolved locally during signaling



11

Connections and Signaling




- Permanent vs. switched virtual connections (PVC/SVC)
 - static vs. dynamic. PVCs last "a long time"
 - E.g., connect two bank locations with a PVC
 - SVCs are more like a phone call
 - PVCs administratively configured (but not "manually")
 - SVCs dynamically set up on a "per-call" basis
- Topology
 - point to point, point to multipoint, multipoint to multipoint
- Challenges: How to configure these things?
 - What VCI to use?
 - Setting up the path

SVC Connection Setup




Virtual Circuits In Practice




- Asynchronous Transfer Mode - ATM: Teleco approach
 - Kitchen sink. Based on voice, support file transfer, video, etc., etc.
 - Intended as IP replacement. That didn't happen. :)
 - Today: rarely used.
- MPLS: The "IP Heads" answer to ATM
 - Stole good ideas from ATM
 - Integrates well with IP
 - Today: Used inside many transit networks to provide traffic engineering, VPN support, simplify core.
- Other networks just run IP.
- Older tech: Frame Relay
 - Only provided PVCs. Used for quasi-dedicated 56k/T1 links between offices, etc. Slower, less flexible than ATM.

Outline




- Circuit switching refresher
- Virtual Circuits - general
 - Why virtual circuits?
 - How virtual circuits? -- tag switching!
- Two modern implementations
 - ATM - teleco-style virtual circuits
 - MPLS - IP-style virtual circuits
- Virtual LANs
 - How do they differ?

ATM History




- Telephone companies supported voice telephony: 4 kHz analog, 64 kbs digital
- They provided lines for data networking
 - ISDN: 64 kbps and faster channels
 - T1 (1.544 Mbps)
 - T3 (44.736 Mbps)
- Wanted to become the primary service provider for data networking services
 - file transfer: bursty, many Mbps peak
 - database access: bursty, low latency
 - Multimedia: synchronized
 - Video: 6 MHz analog, 1.2-200 Mbps digital

Cell Switching





- Small, fixed-size cells
[Fixed-length data][header]
- Why?
 - Voice only needs small “packets”
 - Efficiency: All packets the same
 - Easier hardware parallelism, implementation
 - Switching efficiency:
 - Lookups are easy -- table index.
 - Result: Very high cell switching rates.
 - Initial ATM was 155Mbit/s.
 - Ethernet was 10Mbit/s at the same time. (!)

ATM Features




- Fixed size cells (53 bytes).
- Virtual circuit technology using hierarchical virtual circuits (VP,VC).
- PHY (physical layer) processing delineates cells by frame structure, cell header error check.
- Support for multiple traffic classes by adaptation layer.
 - E.g. voice channels, data traffic
- Elaborate signaling stack.
 - Backwards compatible with respect to the telephone standards
- Standards defined by ATM Forum.
 - Organization of manufacturers, providers, users

The ATM Cell (UNI)




19

ATM Discussion



- Vision: ATM is a replacement for IP.
 - Could carry both traditional telephone traffic (CBR circuits) and other traffic (data, VBR)
 - Simple switching core: forwarding based on VC identifiers
 - Better than IP, since it supports QoS, traffic engineering
- Reality: Traffic engineering benefits were attractive
 - Fast VCI lookup became less critical over time
- But: Complex technology.
 - Signaling software is very complex
 - Technology did not match people's experience with IP
 - supporting connection-less service model on connection-based technology is painful
 - deploying ATM in LAN is complex (e.g. broadcast)
 - With IP over ATM, a lot of functionality is replicated

MPLS



- Multi-Protocol Label Switching
- Bringing virtual circuit concept into IP
- Driven by multiple forces
 - QoS
 - Traffic engineering
 - High performance forwarding
 - VPN

Layer 3 (IP) header

Layer 2 header


Layer 3 (IP) header

MPLS label


Layer 2 header

Some MPLS slides from H. Zhang


MPLS Vocabulary: LSP




- Label-switched path (LSP)
 - Simplex path through interior network
 - Forces packet along a specific path (set of routers)




MPLS Vocabulary: LSR




- Label-switching router (LSR)
 - Performs LSP setup and MPLS packet forwarding
 - Label Edge Router (LER): LSP ingress or egress
 - Transit Router: swaps MPLS label, forwards packet



MPLS Header




- IP packet is encapsulated in MPLS header and sent down LSP





- IP packet is restored at end of LSP by egress router
 - TTL is adjusted, transit LSP routers count towards the TTL
 - MPLS is an optimization – does not affect IP semantics

MPLS Header



- Label
- Class of service
- Stacking bit
 - Remember me?
- Time to live
 - Decrement at each LSR, or
 - Pass through unchanged


Forwarding Equivalence Classes



Packets are destined for different address prefixes, but can be mapped to common path

- FEC = "A subset of packets that are all treated the same way by a LSR"
- The concept of FECs provides for a great deal of flexibility and scalability
- Can be used to force flows of different "sizes" (e.g., Mbps) to follow certain paths through the network – more flexible than traditional routing



Establishing LSPs



- Use the Label Distribution Protocol (LDP) to establish paths based on IP forwarding tables
 - Simple
 - MPLS packets follow the same path as IP
- Explicitly route circuits
 - More work
 - Provides finer grain control over how traffic is distributed throughout the network
 - Important tool for traffic engineering



27

LSPs Driven by IP Routing





- A LSP is actually part of a tree from every source to that destination (unidirectional).
- A control protocol (e.g. Label Distribution Protocol, LDP) builds the tree based on the IP forwarding tables.

MPLS Builds on Standard IP




- Destination based forwarding tables as built by OSPF, IS-IS, RIP, etc.

Label Switched Path (LSP)




Explicitly Routed - ER-LSP

Route=
{A,B,C}




ER-LSP follows route that source chooses. In other words, the control message to establish the LSP (label request) is **source routed**.

Explicitly Routed LSP - Example




Outline




- Circuit switching refresher
- Virtual Circuits - general
 - Why virtual circuits?
 - How virtual circuits? -- tag switching!
- Two modern implementations
 - ATM - teleco-style virtual circuits
 - MPLS - IP-style virtual circuits
- Virtual LANs
 - How do they differ?

VLAN Introduction




- ◆ VLANs logically segment switched LANs (layer 2!) based on organization or function, independent of their physical location in the network
 - ◆ Devices on a VLAN share their own (private) LAN
 - ◆ Form their own IP subnet
- ◆ Offers many benefits:
 - ◆ Performance: limits broadcast messages to the VLAN – improves scalability
 - ◆ Security: isolates VLAN – VLANs connected by routers with smarter filtering capabilities
 - ◆ Management: manage network topology without changing the physical topology

VLAN Example




- VLAN 1
- VLAN 2
- VLAN 3



- A switch creates a broadcast domain
- VLANs help manage broadcast domains
- VLANs can be defined on port groups, users, or protocols
- LAN switches and network management software provide a mechanism to create VLANs


35

VLAN Types




- ◆ VLANs are implemented by switches
- ◆ VLAN memberships can be controlled by a switch in different ways, based on:
 - Port: incoming ports are tagged with VLAN ID
 - MAC address: switch has (MAC, VLAN ID) table
 - Protocol: switch as (protocol, VLAN ID) table
- ◆ The frame headers are encapsulated or modified to insert a VLAN ID
 - ◆ Is inserted by first switch before forwarding packet
 - ◆ Removed by last switch before forwarding to the destination device

Example: 802.1Q Standard for VLANs over Ethernet




- A 32 bit VLAN header is inserted after the MAC addresses



- Header consists of
 - Tag Protocol Identifier (16b): single value that marks frame as a VLAN frame
 - Control bits (4b): mostly priority
 - VLAN Identifier (12b): identifies VLAN

37

Take Home Points



- Costs/benefits/goals of virtual circuits
- Cell switching (ATM)
 - Fixed-size pkts: Fast hardware – limited benefit
 - Packet size picked for low voice jitter. Understand trade-offs.
 - Complex technology – not a good fit for IP
- Tag/label swapping - basis for most VCs.
 - Makes label assignment link-local. Understand mechanism.
- MPLS - IP meets virtual circuits (links)
 - Used for VPNs, traffic engineering, reduced core routing table sizes
 - Management of ISPs at layer 3
- Virtual LANs – manage LANs in software
 - Simplifies management of edge networks at layer 2
 - Set up by manager based on organizational structure – no tag swapping